



Aluminum Open Car Trailer Clear View Aero Guard Kit Installation All Lengths



- Always wear protective clothing and eyewear when operating tools.
- Observe safe tool operation as specified in tool operating instructions.

Locate and identify all components supplied with the Aero Guard Kit.

Quantity	Description
1	AOCT Aero Guard Assembly
4	5/16 X 1-1/4 Bolt
8	5/16 Flat Washer
4	5/16 Hex Nut

Figure 1



Figure 2



1. Set the Aero Guard assembly on the front of your Aluminum open car trailer. Position the Aero Guard assembly centered on the trailer and with the radius corners aligned with the radius corner castings on the trailer. See Figure 1.
2. Mark the locations of the slots in the bottom flange of the Aero Guard on the trailer. Remove the Aero Guard. Drill 3/8" holes at the 4 mounting locations marked. Re-position the Aero Guard assembly. Place a washer under the head of the bolt then insert through the Aero Guard and the drilled hole at all four locations. See Figure 2. Place a washer and a nut on the bottom side of each bolt, tighten to 14 Ft-lbs.
3. Periodically check bolts for proper tightness.